



LEVEL

LES 061..
LES 061K..
LES 065..
LES 071..
LES 071K..
LES 075..
LES 081..
LES 081K..
LES 085..
LES 131..
LES 131K..
LES 135..



1


Montaggio Assembly




$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX




OK

2


a



b





c



065
075
085
135

d





e

065

075

085



135



3







Fissaggio ZSCA050..
ZSCA050.. Assembly

061K..
071K..
081K..
131K..



M

Manutenzione
Service





S**b**

Sostituzione Aeratore How to replace Aerator

071 071K 075

081 081K 085

a

Sostituzione Cartuccia How to replace Cartridge

C

