

STEEL


STEEL 022..

STEEL 026..

STEEL 168..

STEEL 168D..


STEEL 168R..



IST036
Rev.2016.01

1


Montaggio
Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX





OK

2



022
026
168
168D
168R



a




D

Deviatore
Diverter


022
026









168
168D



168R








Sostituzione Cartuccia How to replace Cartridge

022
026
168
168D
168R



S

Sostituzione Sede Calotta How to replace Seat for Nut

b


022

026

168

168D

168R



C

