


TANGO TILT

071..
071K..
075..
081..
081K..
085..
131..
131K..
135..



COMPATIBILITY:


TA
TI



IST133
Rev.2018.02

1


Montaggio Assembly




$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$



MIN - MAX



OK





2

a

071 071K 075
081 081K 085
131 131K 135

b


c




075
085
135

d


071 071K 075
081 081K 085
131 131K 135



CH9



G 3/8"




075

085

135

e



3


Fissaggio ZSCA050..
ZSCA050.. Assembly

071K..


081K..

131K..

a



c





b

CH 4

d

F

Funzionamento Working









085

081

081K

M

Manutenzione Service




S Sostituzione Cartuccia How to replace Cartridge

TANGO

071 071K 075

081 081K 085

131 131K 135





Sostituzione Cartuccia How to replace Cartridge

TILT

071 071K 075


081 081K 085

131 131K 135



c Sostituzione Snodo e Aeratore How to replace Joint and Aerator

131 130 135



d Sostituzione Aeratore How to replace Aerator

071 071K 075

081 081K 085

131 131K 135

